

# Heat sink drilling template for single xrf-286 amplifier (v3)

Using a #36 drill bit  
(.1065), drill these 2  
holes to a depth of  
.250; then tap 6-32  
to a depth of .187

Using a #43 drill bit (.089),  
drill the remaining 8 holes  
to a depth of .250; then tap 4-  
40 to a depth of .187

